



ORDERING INFORMATION
PART NUMBER CODE FOR PRESSURE RATED HYDRAULIC CYLINDERS
SERIES JHDH STANDARD CONSTRUCTION CYLINDER
SERIES LSSE ALL-STAINLESS STEEL CYLINDER

H 2 0 S 0 2 7 5 A B 0 2 0 0

MODEL CODE: *
 H, for standard JHDH hyd. cylinder
 E, for all stainless steel LSSE hyd. cylinder

BORE SIZE:
 For 1" use 01
 For 1 1/2" use 15
 For 2" use 20
 For 2 1/2" use 25
 For 3 1/4" use 32
 For 4" use 40
 For 5" use 50
 For 6" use 60

ROD DIAMETER:
 For Standard, use S
 For 1st Oversize, use 1
 For 2nd Oversize, use 2
 For 3rd Oversize, use 3

STROKE:
 Stroke in inches

FRACTIONAL STROKE:
 In 0.01 inch increments

SPECIAL INFORMATION:
 For no modifications, use 00
 For special items, use 0S
 (CONSULT LEHIGH)

MOUNTING STYLE:

For #1 (MX0)	use 01
For #2 (MX1)	use 02
For #3 (MX2)	use 03
For #4 (MX3)	use 04
For #5 (MS1)	use 05
For #6 (MF1)	use 06
For #7 (MF2)	use 07
For #8F (MP1)	use 8F
For #8D (MP2)	use 8D
For #8M (MP3)	use 8M
For #8S (MP5)	use 8S
For #9 (MS4)	use 09
For #10 (MNR1)	use 10
For #11 (MS2)	use 11
For #12 (MT2)	use 12
For #13 (MT1)	use 13
For #14 (MT4)	use 14
For #15 (MS7)	use 15
For #16 (MF5)	use 16
For #17 (MF6)	use 17

CUSHIONS:
 For Cushions both ends, use B
 For Cushions cap end, use R
 For Cushions rod end, use F
 For no cushions, use N

ROD END STYLE:
 For Small Male (Standard), use A
 For Female, use B
 For Full Male, use C
 For Intermediate Male, use D
 For Flanged Rod End, use F
 For Plain Rod End, use P

* SEE APPLICABLE PRODUCT SECTION FOR ALL OTHER PRODUCTS; e.g. POSITION SENSING, BOOSTER, INTENSIFIER, SPRING CYLINDER

Cylinder Designation for Sample Code Above

Series JHDH Standard Construction Hydraulic Cylinder – 2" Dia. Bore
 5/8" Dia. Rod – 2.75" Stroke – Standard Small Male Rod End (7/16–20)
 Cushioned Both Ends – #2 (MX1) Mounting